


Technical Data Sheet

GL PROPORTIONAL



General description

- Sturdy and versatile transmitter for proportional applications
- Variable positioning of the controls possible
- Range of application: industrial applications, building industry, vehicle technology, agriculture, etc.
- Key switch, stop button, toggle switch, push button, battery compartment, belly belt, 6 control levers maximum with stepless control in each direction
- Several types of feedback available



Control functions and accessories

- 1 Start button
- 2 Key switch
- 3 Stop button (push / pull)
- 4 Control levers (proportional)
- 5 Toggle switches
- 6 LED status display
- 7 Battery charger with original HETRONIC battery

NOTE: Only use genuine HETRONIC parts.
Not doing so introduces the risk of serious damages and will result in the loss of your guarantee.



Technical Data Sheet

Safety check

Attention: You have to read and understand the operating manual of the radio remote control and the machine before operation is started!

Check the proper operation of the **stop button** before operating the machine.

Please check the following items each time before using the system!

- Check the transmitter for damages
- Check the function of the stop button by means of the LED status display ⑥ (transmitter on: LED is flashing / stop button pushed: LED is flashing faster)
- When the transmitter is switched on, you will hear an acoustical signal (standard adjustment)

Operation of the transmitter

The transmitter may only be operated by instructed persons!

Insert a fully charged battery into the battery compartment of the transmitter.

Start the transmitter by using the **key switch** ②. Now, the **LED status display** ⑥ has to flash green and an acoustical signal will prove the system check (approx. 2 seconds).

After the system check you may start the system by activating the **start button** ①. You can control the designated function by activating the **control levers** ④, **toggle switches or push buttons**. The activated functions are now transmitted to the receiver. The individual functions of the buttons are described in the enclosed drawings! You can stop the system using the **stop button** ③ (only use in case of an emergency).

LED status display: Flashing = transmitter activated

Buzzer: A low voltage is signalled by an intermittent sound.
After approx. 30 seconds the transmitter switches off.

Technical data

Dimensions

Material	Polyamid with glass fibre
Weight	1400 g
Dimensions	H 183/ B 297/ T 180 mm
Diagnostics	Status LED
RF technology	Synthesizer
RF output	< 10 mW
Temperature range	-25° up to +70° C
Antenna	internal
Frequency range	434/869 Mhz (for EU, further frequencies on request)
Safety address	20 bit (1 Mio.)
Protection type	IP 65 (exceeds Nema 12/13)
Operating time	more than 20 h possible
Power supply	3,6 V DC

